Dexion | Digital Dynamic Aisle Lock



Product overview

The Dexion Digital Dynamic Aisle Lock offers Keypad or RFID operated locks, taking the pain out of key management with enhanced lock functionality and assigned use operation. This lock provides security for individual aisles within the Freetrack2 and Mekdrive3 Compactus fitted with Ultima CI-80 shelving.

Facility staff will appreciate a selection of Basic or Advanced lock management systems including Electronic Keys to enable master key access, quickly program large quantities of locks or download audit trails. Installation of these low maintenance locks is quick and easy. RFID locks can often be operated via users existing customer RFID cards/credentials.

Technical specifications

Lock Type	Battery Powered	Max. No. Of Consecutive Secured Bays	2 bays (1 aisle)
Lock Operation	Keypad / RFID	Colour Options	Brushed Nickel and Matte Black
Lock Functionality Lock Engagement	'Code Managed' or 'Key Managed' Models 'Assigned' Use Rotating Cam	Features	Audible and visual indicators Audit trail downloads Accessibility extended handles
0 0	J		Vertical body orientation
RFID Lock Compatibility	Compatible with 13.56 MHz RFID Standards - iClass, FeliCa, HID SEOS, DESFire and MIFARE	User RFID Credential Accessories	Card / FOB / Bracelet / Adhesive Label
Dexion Product Applications	Freetrack2 Compactus Mekdrive3 Compactus	Electronic Key Accessories	Data / Programming / Manager Bypass / User / Reset

_		
Co	nta	ct

For more information on the Dexion Dynamic Aisle Lock please contact us on 1300 180 358.

Disclaimer:

The Information contained herein is the intellectual property of Dexion. The Information is defined to include: data, text, images, specification, graphics, design details and any and all other information whatsoever contained herein. The Information has been produced exclusively for Dexion and may not be used for any other purpose. None of the information may be used, altered, edited, copied, distributed or duplicated in any way without the express written consent of Dexion. Whilst the utmost care is taken to ensure the accuracy of the information contained herein, Dexion makes no quarantee as to its accuracy. Dexion shall, under no circumstances, be liable for any costs, losses, expenses or damages which may in any way be attributable to the use or adoption of such data and/or design details. All dimensions indicated are nominal only. Dexion reserves the right to alter or amend any of the information herein, including data and design details, without prior notice.

